




## Classic Menu Items Status, Charge, Mode, Aux, Misc, Logs, Tweaks, Temps and Net






(R) Symbolizes pushing the Right Soft Key

(L) Symbolizes pushing the Left Soft Key

**WARNING!** The Classic's USB port is NOT isolated from battery negative. This is typically only an issue on positive ground systems or systems with a tripped ground fault protection device. Care must be taken that a computer connected to the Classic's USB port is either isolated from ground and the Classic's negative or that the computer's USB negative is common with the Classic's negative and ground.





(R) Symbolizes pushing the Right Soft Key  
 (L) Symbolizes pushing the Left Soft Key




# CLASSIC MENU MAP

MidNite Solar Inc.

Continued from previous page.

## AUX 2 MENU



(R) Symbolizes pushing the Right Soft Key


(L) Symbolizes pushing the Left Soft Key

[www.midnitesolar.com](http://www.midnitesolar.com)

17722 - 67th Ave NE Arlington, WA 98223




PH. 360-403-7207 Fax 360-691-6862

## MISC MENU



# CLASSIC MENU MAP

MidNite Solar Inc.



- (R) Symbolizes pushing the Right Soft Key
- (L) Symbolizes pushing the Left Soft Key

